STEP 1
PREPARE YOUR HYDRAULIC KIT&CHARGING
BAR



STEP 2
REMOVE GEARBOX UPPER PIPE



STEP 3
RELEASE THE SPRING BETWEEN PLATES



STEP 4 REMOVE PINS



STEP 5
TAKE OFF THE STANDARD CHARGING BAR



STEP 6 PREPARE HYDRAULIC KIT CHARGING BAR



STEP 7
MOUNT HYDRAULIC CHARGING BAR



STEP 8 CONNECT STRECHER LAMMA'S (PLATES) WITH CHARGING BAR



STEP 9
CONNECT HYDRAULIC KIT WITH CHARGING BAR



STEP 10 CONNECT HYDRAULIC KIT WITH UPPER PLATE



STEP 11
RE-ATTACHED THE TENSION SPRING

